

---

## **UHF/VHF RX Tester**

### **Features**

- Pocket size
- Built-in speaker
- Equipping with a 2.5 mm earphone and a 3.5 mm CI-V mini jack
- 5 section RSSI bargraph to show relative RF signal strength
- Incorporating an ICOM CI-V interface for tuning with the RW-00X series
- Enabling to hold on an active channel
- Low battery indicator
- Lock indicator to display signal reception
- Low power consumption (Average 5 hour battery life)
- Supplied with NiCd pack, AC wall charger, flexible antenna and earphone



### **Controls**

- VOL Knob - This knob turns the tester on and adjusts sound volume.
- SQL Knob - This tunes the squelch up or down to set the signal strength for reception.
- SKIP Button - This frees the tester from any unwanted signals.
- AUTO HOLD Switch - This automatically stops and holds on an active frequency.

### **Specification**

Frequency range	30 MHz - 900 MHz (Cellular Blocked)
Modulation	FM
Deviation	< 100 KHz
Sensitivity	< -53 dBm at 500 MHz
Impedance	50 Ohms
Battery	Internal 5 x AA 600 mAH NiCd pack
Power	9 VDC 300 mA
Case	Stamped aluminum with black anodized finish
Size	100 mm high x 68 mm wide x 31 mm deep
Weight	280 g